

Ultra-Miniature Raman Spectrometer With Dual-Port Sampling:

1)SERS Reader and 2)Standard Raman Spectrometer

Standard Raman Spectrometer Sampling Port

SERS Substrate/chip



SERS Reader:

Step 1:
Press to Pop Open Reader

Step 2:
Place Sample (SERS Substrate/Chip)

Step 3:
Press to Close Reader Then Measure